

HardieBacker® Cement Board

TOOLS & MATERIALS CHECKLIST

Backer Board

- HardieBacker ¼-inch Cement Board – Floors & Countertops
- HardieBacker 500 Cement Board – Walls & Ceiling

Cutting

- T-Square/Straightedge
- Utility Knife OR Carbide-Tipped Scoring Blade

Fasteners

- Hammer
- 1¼-inch Corrosion-Resistant Roofing Nails

OR

- Drill
- 1¼-inch Self-Drilling Corrosion-Resistant Screws

Setting Materials

- Square Notch Trowel
- Thin-Set Mortar
 - Unmodified thin-set can be used beneath the backer board
 - Modified thin-set is required above the backer board, but can also be used beneath the backer board
- 2-inch Wide Alkali-Resistant Fiberglass Joint Tap
- Sponge
 - Use a sponge to wet down the backer board before applying thin-set above the backer board

For more information, or to download full installation instructions, [visit HardieBacker.com](https://www.hardiebacker.com).